

# SPECIFICATION SHEET

## **Deck & House Cleaner**

Product:16151

2/2016

### **DESCRIPTION:**

Daly's **Deck & House Cleaner** is formulated for use on all painted, stained, unfinished or weathered wood surfaces, to remove mildew, mold, algae, dirt and in some cases, deteriorated stains. Use also for routine cleaning, and preparing surfaces prior to painting. **Deck & House Cleaner** is the recommended method prior to application of Daly's DECKSTAIN.

## **RECOMMENDED USES:**

For use on exterior wood decks, siding, fences, railings, steps and coated surfaces including aluminum, plastic and vinyl.

### **RECOMMENDED SYSTEMS:**

It is recommended to first test product on a small, hidden area for desired results

- 1. SHAKE WELL. Add 1 part cleaner to 4 parts water in a clean, plastic pail or bucket. 5 gallons of mix will cover approximately 800-1000 sq.ft.
- 2. Apply liberally, using a synthetic bristle brush or pump-type sprayer. Do not apply in direct sunlight or to hot surfaces.
- 3. Let sit 10-15 minutes. Stubborn areas may require scrubbing with a stiff fiber brush. If surface begins to dry, lightly mist with water.
- 4. Rinse surface thoroughly with water using a garden hose with nozzle at maximum pressure, or pressure washer. Repeat procedure if necessary.

Important: Allow cleaned surfaces to dry completely before staining or painting. Do not apply at temperatures below  $50^{\circ}$  F.

**CLEAN UP:** Rinse equipment and over-spray areas thoroughly with water. Rinse container, do not reuse.

**COVERAGE**: 5 gallons of mix will cover approximately 800-1000 sq. ft.

**WEIGHT PER GALLON: 8.8 lbx** 

FLASH: Non-flammable

V.O.C.: None

**CONDITIONS TO AVOID:** Do not let dry on glass.

## **CAUTIONS:**

## **DANGER - CORROSIVE**

CONTAINS SODIUM HYPOCHLORITE, AND SODIUM METASILICATE.

## KEEP AWAY FROM HEAT AND FLAMES. KEEP OUT OF REACH OF CHILDREN.

Avoid prolonged contact with skin, eyes and mucous membranes. Wear rubber gloves and splash glasses during application. Wash thoroughly after handling. Close container after each use. Harmful or fatal if swallowed. Use with adequate ventilation. Do not take internally. Wear proper protective equipment such as goggles, plastic or rubber gloves. Close container after each use. NEVER MIX WITH OTHER CHEMICALS, CLEANERS OR DETERGENTS. Mixture may release harmful gases.

**FIRST AID:** If swallowed, call physician immediately. DO NOT INDUCE VOMITING. Give water or milk to drink. In case of eye contact, flush immediately with plenty of water; for skin, wash thoroughly with soap and water.

When applying and rinsing cleaner, surfaces such as ladders, scaffolding and walking areas may become slippery. Rinse thoroughly to remove from such surfaces.

## **KEEP OUT OF REACH OF CHILDREN**

## SPECIAL INSTRUCTIONS:

DO NOT FREEZE. However, if product is frozen, allow to thaw at room temperature, do not force thaw.

Protect shrubs, wet with water, cover with plastic. Rinse shrubbery and any other exposed surface well with hose, when job is done.

#### NOTE:

- 1. Daly's **Deck & House Cleaner** is not a paint remover. However, it can be successful in removing paint and stain from a deteriorating surface.
- 2. Problem Areas: For a stronger solution, mix 1 part cleaner to 1 part water, and follow procedure.
- 3. May be applied to a damp surface, but not a wet surface.
- 4. For removing discoloration, rust stains and making weathered wood look new, use Daly's WOOD BRIGHTENER.
- 5. For restaining decks, use Daly's Deck Stain.
- 6. Always test product first on a small, hidden area to check for desired results.
- 7. Do not let dry on glass surfaces.

### **REGULATORY:**

Request Material Safety Data Sheet for information pertinent to EPA SARA Title III Section 313 Supplier Notification.

## Daly's Wood Finishing Products

4522 S 133rd St, Tukwila, WA 98168 www.dalyswoodfinishes.com

phone(206) 244-8844

toll free(800) 727-9694

fax(206) 246-7691